

- 9 of 3" hinge pre-drill holes, use 18 of 1/2" srews
- 16 of 1" elbows
- 8 of 1" T's
- a cut 6 1" pipe at 19 3/4"
- **b** cut 6 1" pipe at 30"
- c cut 8 1" pipe at 29"
- d cut 8 1" pipe at 38"

Also need 18 of 1/2" metal screws and 1 can of pvc cement

Curtain: 118" wide by 73" tall - so you can wrap around backside and also on top. Use industry velcro.